

Tumor Spheroid Fabrication and Encapsulation in Polyethylene Glycol Hydrogels for Studying Spheroid-Matrix Interactions

Joseph Bruns¹, Shabnam Nejat¹, Allison Faber¹, Silviya P. Zustiak¹

¹ Biomedical Engineering Department, Saint Louis University

Corresponding Author

Silviya P. Zustiak

silviya.zustiak@slu.edu

Citation

Bruns, J., Nejat, S., Faber, A., Zustiak, S.P. Tumor Spheroid Fabrication and Encapsulation in Polyethylene Glycol Hydrogels for Studying Spheroid-Matrix Interactions. *J. Vis. Exp.* (199), e65515, doi:10.3791/65515 (2023).

Date Published

September 22, 2023

DOI

10.3791/65515

URL

jove.com/video/65515

Abstract

Three-dimensional (3D) encapsulation of spheroids is crucial to adequately replicate the tumor microenvironment for optimal cell growth. Here, we designed an *in vitro* 3D glioblastoma model for spheroid encapsulation to mimic the tumor extracellular microenvironment. First, we formed square pyramidal microwell molds using polydimethylsiloxane. These microwell molds were then used to fabricate tumor spheroids with tightly controlled sizes from 50-500 μm . Once spheroids were formed, they were harvested and encapsulated in polyethylene glycol (PEG)-based hydrogels. PEG hydrogels are a versatile platform for spheroid encapsulation, as hydrogel properties such as stiffness, degradability, and cell adhesiveness can be tuned independently. Here, we used a representative soft (~ 8 kPa) hydrogel to encapsulate glioblastoma spheroids. Finally, a method to stain and image spheroids was developed to obtain high-quality images via confocal microscopy. Due to the dense spheroid core and relatively sparse periphery, imaging can be difficult, but using a clearing solution and confocal optical sectioning helps alleviate these imaging difficulties. In summary, we show a method to fabricate uniform spheroids, encapsulate them in PEG hydrogels and perform confocal microscopy on the encapsulated spheroids to study spheroid growth and various cell-matrix interactions.

Introduction

Tumor spheroids have emerged as useful *in vitro* tools in studying cancer etiology, pathology, and drug responsiveness¹. Traditionally, spheroids have been cultured in conditions such as low adhesion plates or bioreactors, where cell-cell adhesion is favored over cell-surface adhesion². However, it is now recognized that to recapitulate

the tumor microenvironment more faithfully, *in vitro* spheroid models should capture both cell-cell and cell-matrix interactions. This has prompted multiple groups to design scaffolds, such as hydrogels, where spheroids can be encapsulated^{3,4}. Such hydrogel-based spheroid models enable the elucidation of cell-cell and cell-matrix interactions

on various cell behaviors, such as viability, proliferation, stemness, or therapy responsiveness³.

Here, we describe a protocol for the encapsulation of glioblastoma spheroids in polyethylene glycol (PEG) hydrogels. There are multiple literature reports of glioblastoma cell spheroid encapsulation in hydrogels. For example, spheroids were formed by encapsulating U87 cells in PEG hydrogels decorated with an RGDS adhesive ligand and crosslinked with an enzymatically cleavable peptide to determine the effect of hydrogel stiffness on cell behavior⁵. U87 cells have also been formed in other PEG-based or hyaluronic acid-based hydrogels to expand the cancer stem cell population⁶ or to explore matrix-mediated mechanisms of chemotherapy resistance^{7,8,9}. Glioblastoma spheroids have also been encapsulated in gelatin hydrogels to study the crosstalk between microglia and cancer cells and its effect on cell invasion¹⁰. Overall, such studies have demonstrated the utility of hydrogel-based *in vitro* models in understanding glioblastoma pathology and devising treatments.

Further, there are different methods for tumor spheroid fabrication and hydrogel encapsulation¹¹. For example, dispersed cells could be seeded in hydrogels and allowed to form spheroids over time^{5,12}. One drawback of such a method is the polydispersity of the formed spheroids, which could lead to differential cell responses. To produce uniform spheroids, cells could be encapsulated in microgels and cultured for extended periods until they invade and remodel the gel¹³, or cells could be deposited in templated gels with spherical 'holes' and allowed to aggregate¹⁴. The drawback of these methods is their relative complexity, the need for a droplet generator or other means to form microgels or the 'holes' in the gel, and the time it takes for spheroids to grow and mature. Alternatively, spheroids could be pre-formed in

microwells^{9,15,16} or in hanging-drop plates^{17,18} and then encapsulated in a hydrogel, similar to the technique described here. These methods are simpler and can be done in a higher throughput fashion. Interestingly, it has been shown that the method of spheroid formation can affect spheroid cell behaviors, such as gene expression, cell proliferation, or drug responsiveness^{19,20}.

Here, we focus on glioblastoma since it is a solid tumor whose native environment is the soft, nanoporous brain matrix²¹, which can be mimicked by a soft, nanoporous hydrogel. Glioblastoma is also the deadliest brain cancer for which there is no available cure²². However, the protocol described here can be used for the encapsulation of spheroids representing any solid tumor. We chose to use PEG hydrogels that are formed through a Michael-type addition reaction²³. PEG is a synthetic, non-degradable, and biocompatible hydrogel that is inert and serves as scaffolding and physical cell support but does not support cell attachment²³. Cell adhesiveness can be added separately via tethering of whole proteins or adhesive ligands²⁴, and degradability can be added via chemical modifications of the PEG polymer chain or hydrolytically or enzymatically degradable crosslinkers^{25,26}. This allows for biochemical properties to be tuned independently of mechanical or physical hydrogel properties, which could be advantageous in studying cell-matrix interactions. The Michael-type gelation chemistry is selective and happens at physiological conditions; hence, it allows for spheroid encapsulation by simply mixing the spheroids with the hydrogel precursor solution.

Overall, the methodology presented here has several notable characteristics. First, fabricating tumor spheroids in a multiwell assembly is efficient, quick, and the cost of the required materials is low. Second, the spheroids are produced

in large batches in a variety of sizes with low polydispersity. Finally, only commercially available materials are required. The utility of the methodology is illustrated by exploring the effect of substrate properties on spheroid cell viability, circularity, and cell stemness.

Protocol

1. Solutions preparation

1. Preparation of polydimethylsiloxane (PDMS) precursor solution

1. Prepare the negative PDMS precursor solution (also used for the glue precursor solution). Scoop the elastomer into a weigh boat using a spatula and weigh it. Add the curing agent to the elastomer base at a 1:10 ratio. Mix the PDMS and curing agent gently and thoroughly using the spatula in the plastic weigh boat.

NOTE: This PDMS precursor solution is poured into the 6-well square pyramidal microwell plate to form the negative mold. This is the same solution that is used for the glue precursor solution.

2. Prepare the positive PDMS precursor solution. Scoop the elastomer base into the weigh boat using a spatula and weigh it. Add the curing agent to the elastomer base at a 1:9 ratio. Mix the PDMS and curing agent gently and thoroughly using the spatula in the plastic weigh boat.

NOTE: This PDMS precursor solution is later poured onto the negative mold to form the positive mold.

2. Preparation of 0.3 M triethanolamine (TEA) buffer of pH 8

1. Pipette 1 mL of TEA and 9 mL of 1x phosphate-buffered saline (PBS) to a 50 mL conical using a

pipette aid to create a 0.75 M TEA solution. Titrate the solution to a pH of 8 using 1 N HCl or 1 N NaOH. Then, add enough 1x PBS to achieve a final volume of 25 mL to achieve a final TEA concentration of 0.3 M with a pH of 8.

CAUTION: Store HCl and NaOH solutions in a flammable cabinet at room temperature (RT). Wear personal protective equipment when handling.

3. Preparation of complete media

1. To prepare the complete media, add 10% (w/v) or 56 mL of fetal bovine serum and 1% (w/v) or 5.6 mL penicillin and streptomycin to 500 mL RPMI medium.
2. Place the solution at 37 °C for 10-20 min or until the solution is warm prior to use.
3. Store the solution at 0-4 °C for up to 6 months.

4. Preparation of 20% (w/v) polyethylene glycol (PEG) stock solutions

NOTE: Calculation is based on 100 µL solutions which could be scaled up or down as needed.

1. To prepare a 100 µL stock solution of 20% w/v 4-arm PEG-Acrylate (4-arm PEG-Ac), weigh 20 mg of 4-arm PEG-Ac powder in a microfuge tube. Add 70 µL of 0.3 M TEA buffer, then vortex the solution for about 30 s or until fully dissolved. Account for volume change due to powder dissolution by adding enough TEA buffer (~27 µL) to reach a final solution volume of 100 µL.
2. To prepare a 100 µL stock solution of 20% w/v PEG-diSH, weigh 20 mg of PEG-diSH powder in a microfuge tube. Add 70 µL of TEA buffer, then vortex the solution for about 30 s or until fully dissolved. Account for volume change due to

powder dissolution by adding enough TEA buffer (~27 μ L) to reach a final solution volume of 100 μ L.

NOTE: The PEG powder is very hygroscopic and needs to be stored in a desiccated container at -20 °C. When taking it out of the freezer, allow the PEG powder to thaw for 10 min before opening the bottle to weigh the powder. Purge the bottle with an inert gas such as nitrogen or argon to displace the moist air prior to returning it to the freezer. The stock solution of 4-arm PEG-Ac can be stored at 4 °C for up to 2 weeks prior to use. The stock solution of PEG-diSH needs to be prepared immediately prior to use and cannot be stored because the thiol groups react with each other to form disulfide bonds.

5. Preparation of 2% v/v basement membrane matrix solution

1. To prepare a 2% v/v basement membrane matrix working solution, add 20 μ L of the basement membrane matrix (LDEV-free) to 9.98 mL of complete media and mix thoroughly by pipetting up and down ~10 times. Prepare the solution at 4 °C (on ice), then warm it to 37 °C (in an oven or incubator) and use immediately.

NOTE: The basement membrane matrix will start to form a gel at >10 °C, so be sure to mix the basement membrane matrix solution with complete media at 2-6 °C. The complete media composition is described in step 1.3.

6. Preparation of the cell fixative solution

1. To prepare 1 mL of cell fixative solution containing 4% w/v of paraformaldehyde and 0.1% v/v of nonionic surfactant, first mix 891 μ L of 1x PBS and 108 μ L of paraformaldehyde (37% w/

v concentration), and then add 1 μ L of nonionic surfactant (100% concentration). Mix the solution thoroughly.

NOTE: Fixative solution should be made fresh every time fixation is performed.

CAUTION: Paraformaldehyde is flammable and may form combustible dust concentrations in the air. It causes skin irritation and serious eye damage. Avoid breathing in since it may cause respiratory irritation. Handle paraformaldehyde in a chemical fume hood and wear personal protective equipment. Wash hands thoroughly after handling. The nonionic surfactant causes skin irritation and serious eye damage. Wear protective gloves and eye protection or face protection when handling. To avoid release into the environment, open the bottle in a chemical fume hood. Wash hands thoroughly after handling.

7. Preparation of the staining solutions

1. To prepare 3 mM of 3,3'-dihexyloxacarbocyanine iodide (DiOC), mix 2.65 mg of DiOC in 1 mL of DMSO.
2. To prepare 1.5 mM of propidium iodide solution (PI), mix 1 mg of PI in 1 mL of de-ionized water.

8. Preparation of the spheroid-clearing solution

1. Prepare clearing solutions of 20%, 40%, and 80% v/v of formamide in 1x PBS for spheroid clearing.
 1. To make 10 mL of 20% v/v formamide, mix 8 mL of 1x PBS followed by 2 mL of formamide. To make 10 mL of 40% v/v formamide, mix 6 mL of 1x PBS followed by 4 mL of formamide. To make 10 mL of 80% v/v formamide, mix 2 mL of 1x PBS followed by 8 mL of formamide.

2. After combining formamide and 1x PBS, mix the solution by vortexing for about 30 s.

2. Fabrication of square pyramidal microwells

1. Fabricate negative PDMS mold of square pyramidal microwells as shown in **Figure 1**.

1. Prepare 2 g (~1 mL) of negative PDMS precursor solution and pour it onto one well of a 6-well square pyramidal master mold. Note that 1 mL completely covers one well of the plate. After covering the master mold with PDMS, degas the PDMS precursor solution for 30 min by placing the 6-well square pyramidal plate in a vacuum desiccator. Then, cure the PDMS by placing the plate into a 60 °C oven for 24 h.

NOTE: Ensure the plate lid is removed for degassing and placed back on for curing. Degas the solution in a vacuum desiccator or through purging with an inert gas such as nitrogen or argon. If the negative mold precursor solution still has bubbles after 30 min, indicating inadequate degassing, place it in a vacuum desiccator for an additional 30 min. Use one or multiple plate wells simultaneously to prepare one or more PDMS negative molds. Square pyramidal microwells of different sizes can be used, such as 400 and 800 μm side lengths, as shown in **Table 1**.

The same amount of PDMS is used regardless of the square pyramidal sizes.

2. Once PDMS cures while still warm, carefully remove the negative PDMS mold from the master mold using a spatula and cut the negative mold in a 35 mm in diameter slab using a biopsy punch. Place in a Petri dish and cover with the lid and allow for continued curing RT for an additional 24 h.

NOTE: To remove negative molds, use a spatula to get between the well plate and the PDMS mold and gently pull the negative mold from the master mold. The mold is cut into 35 mm slabs to fit a 35 mm Petri dish. Molds can be made in other sizes to fit plates of different diameters. The 35 mm negative mold slabs can be stored, protected from dust at RT, and reused for 6 months.

2. Prepare positive PDMS mold of square pyramidal microwells.

1. Place the 35 mm slabs of the negative PDMS mold into a 35 mm Petri dish with the textured microwells facing up.
2. Prepare 2.5 g (~1.2 mL) of positive PDMS precursor solution as above and pour it onto the negative mold in the 35 mm Petri dish to completely cover the negative mold. Then degas the precursor solution for 30 min as above and place it into 60 °C oven for 3-4 h.

NOTE: Because PDMS is viscous, a bubble can form from air trapped under the negative mold. If a bubble forms under the negative mold, push the mold down gently using a spatula to release the bubble. If air bubbles remain, continue degassing for 30 min, or take a spatula and gently stir the positive mold solution until the bubbles pop.

3. Once the positive PDMS mold cures, remove the molds from the 35 mm Petri dish and immediately peel the positive mold from the negative mold.

NOTE: Timing is important for successful peeling of the positive mold. Removal is best done by slightly cutting into the positive mold using a razor to expose the interface between the positive and negative mold

and peeling the molds from each other. Then peel away the edges of the circular mold. Gently peel the negative mold from the positive mold.

- Glue the molds to the bottom of the wells of a 48-well plate.

NOTE: Here, a 48-well plate is used, but other plates can be used as long as the mold slabs are cut into the correct diameters (for example, 6 mm in diameter for a 96-well plate).

- Cut the positive molds into slabs using a 10 mm biopsy punch.

NOTE: Approximately 4 molds (each 10 mm in diameter) can be cut from one 35 mm diameter positive mold.

- To glue the molds to the bottom of a 48-well plate, prepare the PDMS glue precursor solution (~0.5 mL or 1 g) as previously described²⁷. Use tweezers to gently dip the flat side (not the side with the pattern of microwells) of the 10 mm positive mold into the PDMS precursor solution. Carefully place one mold per well of a 48-well plate, and gently press each mold to the well bottom using the tweezer. Place the assembled plate in a 60 °C oven for 4-24 h to allow the PDMS glue to cure.

NOTE: If PDMS glue precursor solution gets on the positive mold microwells, it can be wiped off using soft tissue paper, and the step can be repeated. When gluing, make sure that the glue does not cover the microwells.

- Sterilize molds by adding 300 µL of 70% ethanol into each well of the 48-well plate using a 1000 µL pipette. Aspirate the 70% ethanol and place the 48-

well plate uncovered in a tissue culture hood under UV (302 nm) for 2 h.

NOTE: Molds can be used for 6 months and re-sterilized as needed.

3. Multicellular tumor spheroid formation, harvest, and encapsulation in hydrogels

NOTE: The protocol outlined in this section is for U87 human glioblastoma cell line (see **Figure 1** and **Figure 2**), but a similar protocol could be used with other cancer cell types.

1. Multicellular tumor spheroid formation

- Wash microwell molds first with an anti-adherence rinsing solution by adding 300 µL of the solution to each well using a 1000 µL pipette. Then, centrifuge at 1620 x g for 3 min and aspirate the solution using a vacuum pump and a Pasteur pipette.

NOTE: Perform this step immediately prior to cell seeding.

- Expose the cells to ~80 µL of 0.25% trypsin/EDTA per each cm² of the culture flask area for 5 min at 37 °C. For example, 1 mL of trypsin/EDTA is appropriate for a T-25 cell culture flask. Neutralize the trypsin by adding the same volume of complete cell culture medium. For example, add 1 mL of complete medium to the trypsin-containing T-25 cell culture flask. Collect the cells from the tissue culture flask.

- Transfer 10 µL of the cell suspension into each port of a hemocytometer for cell counting. Use an inverted microscope to count the total number of cells and average that cell count from at least 8 quadrants, ensuring that the cell number in each hemocytometer quadrant is 20-50 for good cell count

results. Multiply the calculated number by 10^4 to determine the final cell concentration.

4. Resuspend the collected cells in the complete RPMI cell culture medium supplemented with 10% fetal bovine serum and 1% penicillin/streptomycin at a desired final cell concentration, depending on the desired spheroid size, as shown in **Table 1**.

hydrogel

NOTE: The 800 μm microwells will yield ~ 75 spheroid spheroids in one well of a 48-well plate, and the 400 μm microwells will yield ~ 300 spheroids in one well of a 48-well plate.

5. Place 500 μL of cell suspension at the desired concentration in microwells and centrifuge the plate at $1620 \times g$ for 3 min. Place the plate in a humidified incubator at 37°C and 5% CO_2 for 24 h to allow spheroids to form.

NOTE: If spheroids do not form, 2% v/v of the basement membrane matrix combined with complete media can be used to resuspend cells (more details in step 1.5).

2. Spheroids harvesting

1. Using a 1000 μL pipette, firmly pipette 500 μL of spheroids, complete medium into the well. Using 500 μL of

medium from the well, flush the four quadrants of the well (specifically the top, bottom, left and right quadrants) by pipetting up and down at the quadrants three to four times to dislodge the spheroids. Gently aspirate the medium containing the spheroids ($\sim 1000 \mu\text{L}$ total) into a microcentrifuge tube using a 1000 μL pipette and allow the spheroids to settle to the bottom.

2. Remove the supernatant and resuspend the spheroids to the desired final concentration. For

example, to achieve ~ 8 spheroids in a 20 μL gel after encapsulation, resuspend the spheroids in 100 μL of media, yielding a spheroid concentration of ~ 75 spheroids/100 μL in the spheroid suspension.

3. Spheroids encapsulation in hydrogels, as shown in **Figure 2**.

1. To create 100 μL of a 10% w/v PEG precursor solution, combine 50 μL of the suspension, followed by 30 μL of 20% w/v 4-arm PEG-Ac and finally 20 μL of 20% w/v PEG-diSH in a microcentrifuge tube. This will give a stoichiometric molar ratio of acrylate (Ac) to thiol (SH) groups ensuring optimal crosslinking. Mix the gel precursor solution by pipetting up and down ~ 10 times.

NOTE: Hydrogel composition, volume, and polymer concentration can be changed as needed. The resultant hydrogels will be slowly degrading and non-cell adhesive. To make the hydrogel cell adhesive, an adhesive ligand such as RGDS can be added. To make the hydrogel enzymatically degradable, an enzymatically degradable peptide crosslinker containing cysteine residues on both ends could be added. When transferring gently pipette the solution twice to dislodge spheroids and bring them into suspension to ensure even distribution of spheroids.

2. Pipette 20 μL of the gel precursor solution in between two parafilm-lined glass slides separated with 1 mm silicon spacers, and place slides with gel precursor solution in 37°C , 5% CO_2 incubator for 15 min to allow for gelation.

NOTE: Ensure the two glass slides are covered in parafilm to create a hydrophobic surface allowing for easy peeling upon gelation. Instead of parafilm,

a hydrophobic coating solution can be used. A 20 μL volume of hydrogel precursor solution will result in a hydrogel slab of ~ 6 mm in diameter and 1 mm in height prior to swelling. Any spacer type and thickness can be used, but it is recommended that the gel thickness is kept at or below 1 mm (thicker hydrogels could limit oxygen diffusion and transport of nutrients to the cells) but larger than the spheroid diameter (so that spheroids are completely encapsulated in the gel). Any volume of the hydrogel precursor solution can be used. The 20-30 μL gels are suitable for a 24-well plate.

3. Once hydrogel gelation is complete, separate the two glass slides and gently peel the gels off the glass plate using a spatula. Place the gels into a 24-well plate, one per well, ensuring the surface containing the spheroids faces up.

NOTE: Spheroids will fall to the bottom of the gel during gelation, so inverting them for culturing will ensure that the spheroids are near the surface of the hydrogel for better access to nutrients and oxygen. Gelation can be monitored by observing any hydrogel precursor solution remaining in the microcentrifuge tube and not used to create slabs by inverting the tube and noting the time the gel stops flowing.

4. Add complete medium ($\sim 500 \mu\text{L}$) to each well and ensure the hydrogel is submerged completely. Place the multiwell plate in a humidified incubator at 37 °C and 5% CO₂ and culture the cells with medium changes every 2-3 days.

NOTE: Hydrogels can be cultured for up to 4 weeks or until the hydrogels degrade, changing the media every other day.

4. Fluorescent staining

1. Cell viability
 1. Use the stain 3,3'-dihexyloxacarbocyanine iodide (DiOC), which stains the mitochondria and endoplasmic reticulum of all cells, to determine cell viability. Use DiOC (3 mM) at a concentration of 0.02 $\mu\text{g}/\text{mL}$. Specifically, use a 20 μL pipette to add 2 μL of DiOC per every 1000 μL of media into the flask culturing the dissociated cells (at least 24 h prior to the formation process of spheroids in section 3). Allow 24 h for the DiOC to stain the cells.
 2. Use the nuclear and chromosome stain, propidium iodide, PI (1.50 mM), which enters only dead cells. To stain the cells, first aspirate all media and rinse the gel by using a 1000 μL pipette to add 500 μL of 1x PBS so the gel is completely submerged.
 3. Aspirate the PBS and add 500 μL of fresh media, followed by 30 μL of the PI solution to each well (i.e., 6 μL per every 100 μL of media). Cover the well plate with aluminum foil to protect it from light. Place the well plate in an incubator at 37 °C and 5% CO₂ and allow 30 min for the PI to stain the dead cells.
 4. Remove the foil and aspirate the media from the wells. Use a 1000 μL pipette to add 500 μL of 1x PBS to submerge the hydrogel. Aspirate the 1x PBS and repeat the rinse two additional times. Add 500 μL of media to each well and image under a fluorescent inverted or confocal microscope.
 5. Calculate the cell viability by comparing the area of DiOC (all cells) to PI (dead cells), as represented in equation 1, using z-stack images from a confocal microscope or an inverted fluorescent microscope.

$$\%Cell\ Viability = \frac{Area\ of\ Spheroid\ Fluorescing\ Green\ (DiOC) - Area\ of\ Spheroid\ Fluorescing\ Red\ (PI)}{Area\ of\ Spheroid\ Fluorescing\ Green\ (DiOC)}$$

Eq. 1.

5. Immunofluorescence fixation, staining, clearing, and imaging of encapsulated spheroids

1. Fixation and staining

1. Aspirate the media from the wells where the hydrogels are cultured, and rinse the hydrogels by pipetting 500 μ L of 1x PBS directly onto the hydrogels. Gently aspirate the 1x PBS.
2. Fix the spheroids in the 24-well plate by using a 1000 μ L pipette to add 500 μ L volume of fixative solution per well. Allow the fixative to soak the gels for 30 min at RT. Remove the fixative solution using a 1000 μ L pipette and discard in a designated waste container.
3. Rinse the hydrogels by adding 500 μ L of 1x PBS to each well. Aspirate the 1x PBS using a 1000 μ L pipette and repeat the PBS rinse two additional times. Store the well plate in 500 μ L of 1x PBS per well at 4 °C for up to 1 week or use immediately.

NOTE: Be careful not to pull the hydrogels into the pipette when aspirating PBS and fixative solution. Do so by tipping the plate to a ~45-degree angle, which will aid in seeing the hydrogels and preventing accidental aspiration.

CAUTION: Formaldehyde is toxic upon inhalation and contact. Handle with gloves in a chemical fume hood.

4. To stain the cells, incubate the hydrogel-encapsulated spheroids with primary antibodies for Nestin (200 μ g/mL) and SOX2 (200 μ g/mL) at a dilution of 1:200 of antibody: PBS. Use a 1000 μ L pipette to aspirate the 1x PBS from the wells. Add

50 μ L of the diluted antibody to each well. Allow 24 h for staining to be completed. Then, remove the staining solution using a 1000 μ L pipette and discard the waste appropriately.

5. Use a 1000 μ L pipette to add 500 μ L of 1xPBS, which is enough to submerge the hydrogel. Aspirate the PBS and repeat it two more times. Store the stained and submerged hydrogel in 1x PBS at 4 °C for up to 2 weeks prior to imaging or image immediately.

NOTE: Minor optimizations may be needed depending on the antibody to ensure proper staining. The concentration (1:200) and time (24 h) are significantly higher than in typical 2D monolayer cell culture because 3D staining requires diffusion through the hydrogel and the spheroids.

2. After staining the spheroids, clear the spheroid to improve transparency for imaging by replacing PBS with a sequential concentration increase of formamide (optional).
 1. Aspirate the 1x PBS from each well. Add 500 μ L of 20% (v/v) formamide to each well and allow the hydrogel to incubate for 90 min. Aspirate the formamide using a 1000 μ L pipette and collect the waste in a waste container.
 2. Add 500 μ L of 40% (v/v) formamide to the well. Allow the hydrogel to incubate in the solution for 90 min. Aspirate the formamide and collect the waste in the waste container.
 3. Add 500 μ L of 80% v/v formamide to each well and incubate for 90 min. Aspirate the formamide and dispose in the waste container. Add 500 μ L of 100% (v/v) of formamide and allow 24 h incubation prior to imaging. When clearing is finished, properly

dispose of formamide waste through the appropriate services of a laboratory waste management system.

NOTE: Clearing allows for confocal imaging into the core of the spheroid and is optional if only the periphery of the spheroid is being investigated.

3. Imaging hydrogel-encapsulated spheroids using confocal microscopy.

Any microscope - inverted, fluorescent, or confocal - can be used for cell imaging; however, confocal allows for the isolation of single planes.

1. Place the hydrogels in chambered wells with glass coverslip bottoms and position the spheroids as close to the coverslip as possible.

NOTE: Glass coverslips or chambered wells with glass coverslip bottoms can be used. It is crucial to keep hydrogels hydrated as dehydrated samples will result in poor imaging quality.

2. Image the samples with a long-working distance objective (10x-20x) to allow for imaging deep into the spheroid using Z-stacks for 3D reconstructions.

NOTE: Higher magnification objectives allow more detailed imaging and optical sectioning but sacrifice image depth.

3. Quantify the amount of signal present in the optical section relative to the total area of the spheroid for both the cleared and uncleared signal using equation 2.

$$\% \text{Spheroid Area Imaged} = \frac{\text{Spheroid area imaged by optical section}}{\text{Total area of spheroid at optical section}} \times 100\%$$

Eq. 2

Representative Results

Spheroid-based drug screening platforms to study chemotherapeutic effects are increasingly sought after due

to the emphasis on modulating the tumor microenvironment upon spheroid encapsulation in biomaterials replicating native tissue. Here we developed a method for multicellular tumor spheroid preparation and subsequent encapsulation and imaging in a 3D hydrogel. The spheroids are prepared in microwell molds (**Figure 3A,B**), which result in spheroids with spherical shapes and tightly controlled polydispersity. **NOTE:**

For example, for spheroids with 3,300 cells per microwell, the average spheroid size was $\sim 250 \mu\text{m}$, and circularity was >0.8 , where 1 is a perfect sphere (**Figure 3C,D**). The percent coefficient of variance (%CV) for spheroid diameter was 19.3%, and %CV for circularity was 4.5%. Spheroid diameters were dependent on the number of cells per microwell, as shown in **Table 1**. Note that some cells in the microwells might not be incorporated in the spheroid and will be washed off during the spheroid harvesting step.

The spheroid is able to be imaged at varying Z-stack depths, allowing for cell viability for each location within the Z-stack (**Figure 4**). Note that due to confocal imaging limitations and the high cell density, the spheroid core could not be imaged fully. As discussed later, spheroid clearing or sectioning might be needed for improved imaging throughout the spheroid. Through this method, the spheroid viability was determined to be high ($\sim 90\%$) immediately post-harvest and encapsulation, even though cell viability dipped slightly to 85% in the spheroid core compared to the periphery. To ensure viability throughout the spheroid, spheroids were dissociated using acutase, and the viability of the dissociated cells was calculated using the same method and found to be equally high ($>90\%$). A max projection utilizing the spheroid stack represents the highest point of light intensity within each location of the Z-stack compressed into one image (**Figure 4B**).

Representative images of free-floating spheroids (no gel) and encapsulated spheroids (PEG gel) stained for stemness markers Nestin and SOX2 are shown in **Figure 5**. Nestin is an intermediate filament and a stem cell marker present in gliomas. SOX2 is a transcription factor for self-renewal, also present in gliomas. SOX2 was found to be co-localized with DAPI in the nucleus, while Nestin was present throughout the cells. The data shows no difference between the gel and no gel conditions, possibly due to the PEG gel used here being inert and not facilitating cell-matrix interactions through integrin signaling.

A major limitation of imaging is the high spheroid density, making it difficult to image into the spheroid core. Common methods to image the spheroid core include sectioning and clearing the sections. This can work well with free-floating spheroids, but sectioning hydrogels is difficult, and

most tissue clearing involves dehydrating samples, which results in deformed samples. Here we adapted a protocol from Kuwajima et al.²⁸ for hydrogel samples to maintain the spheroid structure while still clearing the spheroids. To demonstrate the utility of the clearing method, spheroids were fixed, stained with PI, and cleared (**Figure 6**). **Figure 6A** shows representative images of optical sections at ~90 μ m into cleared and uncleared spheroids and the total area of the spheroid when the spheroid area is filled. When the clearing was performed, the spheroid core could be imaged ~30 μ m deeper, compared to an uncleared spheroid (**Figure 6B**). Clearing can be very beneficial for immunofluorescence, as the spatial organization of biomarkers can be analyzed into the core of spheroids. This method can only be used for fixed samples as the membrane integrity is disrupted.




Figure 1: PDMS mold fabrication and spheroid formation. PDMS precursor solutions are added to square pyramidal microwell plates to form PDMS molds. The dissociated cell suspension is added to the formed PMDS molds and spun down to allow for spheroid formation after 24 h. [Please click here to view a larger version of this figure.](#)




Figure 2: Hydrogel encapsulation, culturing, and imaging. (A) 4-arm PEG-Ac, PEG diSH, and the spheroid suspension is combined in a microcentrifuge tube and (B) mixed well by pipetting up and down to form a gel precursor solution. (C) 20 μ L of the gel precursor solution is pipetted onto a glass slide, and a second glass slide is placed on top of the solution and separated by 1 mm spacers. (D) Hydrogel is transferred to 24 well plates with spheroids facing up and is covered with media (500 μ L). (E) Hydrogel is transferred to a glass coverslip for microscopy imaging. [Please click here to view a larger version of this figure.](#)




Figure 3: Spheroid formation in microwells prior to harvest, 24 h after initial cell seeding in the microwells.

(A) Spheroids in microwell stained with DiOC (Green). Scale bar is 200 μm . (B) Brightfield image of spheroids in microwells. (C) Histogram of spheroid diameter in microwells. (D) Histogram of spheroid circularity in microwells. [Please click here to view a larger version of this figure.](#)




Figure 4: Representative Z-stack confocal image of live spheroid for live dead analysis. (A) Images from 4 slices of Z-stack with DiOC (green) and PI (red). Scale bar is 200 μm . **(B)** Max projection of Z-Stack. **(C)** Cell viability as a function of spheroid depth. [Please click here to view a larger version of this figure.](#)




Figure 5: Nestin and SOX2 immunostaining of free-floating (no gel) and hydrogel-encapsulated (PEG gel) U87 cell spheroids at day 5 of culture. Representative confocal images of the spheroids confirm Nestin (red) and SOX2 (green) expression, which were counterstained with DAPI (blue; nucleus). Scale bar is 100 μ m. Images cropped and zoomed from the white square show the relationship between the nucleus (blue) and SOX2 (green). [Please click here to view a larger version of this figure.](#)




Figure 6: Imaging depth of cleared spheroids. (A) Representative images of spheroids imaged at 91.6 μ m into the spheroid and total spheroid area. (B) Percentage of the spheroid area imaged as depth into spheroid increases. [Please click here to view a larger version of this figure.](#)

Microwell Size (μm)	Number of Cells per Spheroid	Number of Cells per Well	Cell Concentration (cells/mL)	Spheroid Diameter (μm)
400	200	120000	240000	115.4 \pm 13.5
	500	300000	600000	144.6 \pm 14.3
	1000	600000	1200000	176.5 \pm 12.5
800	2000	300000	600000	212.4 \pm 15.7
	3000	450000	900000	258.9 \pm 16.3
	4000	600000	1200000	305.7 \pm 21.6
	5000	750000	1500000	323.4 \pm 29.8

Table 1: Spheroid diameter and microwell size. The calculated number of cells per spheroid, number of cells per well of a 48-well plate, cell concentration, and resulting spheroid diameter depending on the microwell size of the negative PDMS mold.

Discussion

Hydrogel-based multicellular tumor spheroid models are increasingly being developed to advance cancer therapeutic discoveries^{11,13,29}. They are beneficial because they emulate key parameters of the tumor microenvironment in a controlled manner and, despite their complexity, are simpler and cheaper to use than *in vivo* models, and many are compatible with high-throughput screening technologies. The hydrogel biomaterials can be tuned to emulate the tumor extracellular matrix and facilitate cell-matrix interactions, and the spheroid (as opposed to dissociated cells) emulates the cell-cell interactions of the native tumor. Synthetic hydrogels, as demonstrated here, are particularly advantageous because the hydrogel provides the desired structural support and physical and mechanical properties, while adhesive ligands or degradable sequences can be used to independently tune biochemical material properties. Synthetic hydrogels also offer lower batch-to-

batch variability and greater ranges of material properties, encompassing most soft tissues in the body.

Here, we describe in detail the use of an inert PEG-based hydrogel that forms via Michael-type addition as described previously^{25,30}. The representative PEG hydrogel used here has Young's modulus of \sim 8 kPa, similar to glioblastoma tissue stiffness⁹. The PEG hydrogel is convenient as it has tunable properties and highly specific gelation chemistry and can be formed in the presence of spheroids without compromising cell viability (**Figure 4**). While the PEG hydrogel is inert and serves as cell scaffolding with defined physical and mechanical properties, cell adhesive ligands can be added to guide cell-matrix interactions, and enzymatically degradable peptide crosslinkers can be added to aid matrix remodeling⁹. Adhesive ligands and peptide crosslinkers could be selected to emulate the cellular microenvironment to add physiological or pathological relevance to the model. For more details on PEG hydrogel modifications to tune hydrogel degradability,

mechanical properties, and adhesiveness, readers are referred to the following published work^{9,27}.

Using the method described here, large quantities of cancer spheroids can be formed quickly and encapsulated in the PEG hydrogel to explore the effect of substrate properties on spheroid cell viability, morphology, or cell stemness (**Figure 4** and **Figure 5**), among other properties. The cells are first allowed to aggregate and form a spheroid and then encapsulated in the hydrogels, as shown in **Figure 2** and **Figure 3**. The aggregation process enables varying the spheroid sizes based on the size of the microwell molds and the concentration of the cell suspension pipetted into the microwell molds (**Table 1**). The resultant spheroids are relatively monodisperse in size, with an average coefficient of variance of ~10%-20% for all conditions. This is beneficial for a variety of applications, as similar sizes will exhibit similar diffusion limitations, be it of drugs, nutrients, or oxygen, into the spheroid. The spheroids also have a circularity of >0.8, which is comparable to other ultra-low attachment or hanging drop methods³¹. Note that other methods for spheroid formation can be used first, such as the hanging drop method or rotary cell culture system³², and then encapsulated in the hydrogel. However, the method described here does not require any specialized equipment or expensive consumables, hence, aiding in accessibility for all labs.

While the methods shown here use the U87-MG glioblastoma cell line, the spheroid fabrication and encapsulation method described can be used for various cancer cell types that form solid tumors. If the cells do not readily aggregate to form a spheroid, a mixture of ECM proteins, such as a basement membrane matrix, can be added to the cell suspension to aid the process (as described in the methods). Once spheroids

are encapsulated, it is best to be imaged and analyzed directly in the hydrogel instead of being extracted from the hydrogel or the cells being dissociated. This is because spheroids are typically heterogeneous (e.g., a hypoxic core could form due to oxygen and nutrient gradients), and cell responses will differ based on the position within the spheroid. Also, cell extraction might obscure the role of cell-matrix interactions on spheroid fate. For example, we have previously shown that cells in the spheroid periphery versus core have different responsiveness to chemotherapeutics, which is further dependent on the mechanical properties of the substrate²⁷. Hence, we recommend using microscopy techniques for the study of spheroid behaviors, as highlighted in this manuscript.

One issue to consider when imaging dense tissues such as spheroids is their opacity. Here we describe a clearing method to improve imageability through the interior of the spheroid (**Figure 6**). However, even though spheroid clearing aids in maximizing imaging depth, limitations can be found when placing the encapsulated spheroids in formamide resulting in potential structural damage and affecting spheroid imageability. This process also cannot be performed when observing cell viability through live/dead staining because clearing requires fixation. The clearing process also requires several hours of incubation in formamide following staining, so it could potentially impact the dyes being used. Other techniques, such as cryosectioning and then immunostaining, could also work, provided that the sectioning does not distort or compromise spheroid tissue integrity. In our hands, cryosectioning resulted in "squished" spheroids due to the softness of the hydrogel, which is ~8 kPa in Young's modulus, to emulate glioblastoma tissue stiffness.

Overall, the critical steps in this protocol are successful spheroid fabrication, hydrogel encapsulation and culture, and spheroid imaging and analysis; hence, we have provided notes and troubleshooting strategies for those steps. The hydrogel-encapsulated spheroids described here could be used in a variety of applications, such as drug screening platforms, detailed studies of cell-matrix interactions and their effect on cell behaviors, studies of disease etiology, etc. Such studies can be aided by the tunability of the described system as discussed above and the predictable and controllable properties of the synthetic PEG hydrogel. Some limitations of the described system include a medium throughput, where high throughput is preferable for multiplex or high-volume studies such as drug screening. Another limitation is the need for imaging, such as confocal imaging, for data analysis. While imaging allows for detailed special and temporal analysis, it is also time-consuming and hindered by penetration limitations due to depth and spheroid cell density.

Disclosures

The authors have nothing to disclose.

Acknowledgments

This work was funded by start-up funds provided to Dr. Silviya P Zustiak by Saint Louis University as well as by a seed grant from the Henry and Amelia Nasrallah Center for Neuroscience at Saint Louis University awarded to Dr. Silviya P Zustiak.

References

1. Hirschhaeuser, F. et al. Multicellular tumor spheroids: an underestimated tool is catching up again. *Journal of Biotechnology*. **148** (1), 3-15 (2010).
2. Costa, E. C., de Melo-Diogo, D., Moreira, A. F., Carvalho, M. P., Correia, I. J. Spheroids formation on non-adhesive surfaces by liquid overlay technique: Considerations and practical approaches. *Biotechnology Journal*. **13** (1), 1700417 (2018).
3. Li, Y., Kumacheva, E. Hydrogel microenvironments for cancer spheroid growth and drug screening. *Science Advances*. **4** (4), eaas8998 (2018).
4. Kamatar, A., Gunay, G., Acar, H. Natural and synthetic biomaterials for engineering multicellular tumor spheroids. *Polymers*. **12** (11), 2506 (2020).
5. Wang, C., Tong, X., Yang, F. Bioengineered 3D brain tumor model to elucidate the effects of matrix stiffness on glioblastoma cell behavior using PEG-based hydrogels. *Molecular Pharmaceutics*. **11** (7), 2115-2125 (2014).
6. Nakod, P. S., Kim, Y., Rao, S. S. Three-dimensional biomimetic hyaluronic acid hydrogels to study glioblastoma stem cell behaviors. *Biotechnology and Bioengineering*. **117** (2), 511-522 (2020).
7. Xiao, W. et al. Bioengineered scaffolds for 3D culture demonstrate extracellular matrix-mediated mechanisms of chemotherapy resistance in glioblastoma. *Matrix Biology*. **85** 128-146 (2020).
8. Pedron, S. et al. Hyaluronic acid-functionalized gelatin hydrogels reveal extracellular matrix signals temper the efficacy of erlotinib against patient-derived glioblastoma specimens. *Biomaterials*. **219**, 119371 (2019).
9. Hill, L., Bruns, J., Zustiak, S. P. Hydrogel matrix presence and composition influence drug responses of encapsulated glioblastoma spheroids. *Acta Biomaterialia*. **132**, 437-447 (2021).

10. Chen, J. -W. E. et al. Crosstalk between microglia and patient-derived glioblastoma cells inhibit invasion in a three-dimensional gelatin hydrogel model. *Journal of Neuroinflammation*. **17** (1), 346 (2020).

11. Thakuri, P. S., Liu, C., Luker, G. D., Tavana, H. Biomaterials-based approaches to tumor spheroid and organoid modeling. *Advanced Healthcare Materials*. **7** (6), 1700980 (2018).

12. Shin, S. et al. Alginate-marine collagen-agarose composite hydrogels as matrices for biomimetic 3D cell spheroid formation. *RSC Advances*. **6** (52), 46952-46965 (2016).

13. Pradhan, S., Clary, J. M., Seliktar, D., Lipke, E. A. A three-dimensional spheroidal cancer model based on PEG-fibrinogen hydrogel microspheres. *Biomaterials*. **115**, 141-154 (2017).

14. Imaninezhad, M., Hill, L., Kolar, G., Vogt, K., Zustiak, S. P. Templated macroporous polyethylene glycol hydrogels for spheroid and aggregate cell culture. *Bioconjugate Chemistry*. **30** (1), 34-46 (2018).

15. Mirab, F., Kang, Y. J., Majd, S. Preparation and characterization of size-controlled glioma spheroids using agarose hydrogel microwells. *PLoS One*. **14** (1), e0211078 (2019).

16. Razian, G., Yu, Y., Ungrin, M. Production of large numbers of size-controlled tumor spheroids using microwell plates. *Journal of Visualized Experiments: JoVE*. **81**, e50665 (2013).

17. Timmins, N. E., Nielsen, L. K. *Generation of Multicellular Tumor Spheroids by the Hanging-Drop Method*. *Tissue Engineering*. Hauser, H., Fussenegger, M. (eds). *Methods in Molecular Medicine*. **140**. Springer, Humana Press, NJ (2007).

18. Zhao, L. et al. A 3D printed hanging drop dripper for tumor spheroids analysis without recovery. *Scientific Reports*. **9** (1), 19717 (2019).

19. Amaral, R. L., Miranda, M., Marcato, P. D., Swiech, K. Comparative analysis of 3D bladder tumor spheroids obtained by forced floating and hanging drop methods for drug screening. *Frontiers in Physiology*. **8**, 605 (2017).

20. Gencoglu, M. F. et al. Comparative study of multicellular tumor spheroid formation methods and implications for drug screening. *ACS Biomaterials Science & Engineering*. **4** (2), 410-420 (2018).

21. Zhang, C., Liu, C., Zhao, H. Mechanical properties of brain tissue based on microstructure. *Journal of the Mechanical Behavior of Biomedical Materials*. **126**, 104924 (2021).

22. Alifieris, C., Trafalis, D. T. Glioblastoma multiforme: Pathogenesis and treatment. *Pharmacology & Therapeutics*. **152**, 63-82 (2015).

23. Zustiak, S. P., Leach, J. B. Hydrolytically degradable poly (ethylene glycol) hydrogel scaffolds with tunable degradation and mechanical properties. *Biomacromolecules*. **11** (5), 1348-1357 (2010).

24. Zustiak, S. P., Wei, Y., Leach, J. B. Protein-hydrogel interactions in tissue engineering: Mechanisms and applications. *Tissue Engineering Part B: Reviews*. **19** (2), 160-171 (2013).

25. Kroger, S. M. et al. Design of hydrolytically degradable polyethylene glycol crosslinkers for facile control of hydrogel degradation. *Macromolecular Bioscience*. **20** (10), 2000085 (2020).

26. Raeber, G., Lutolf, M., Hubbell, J. Molecularly engineered PEG hydrogels: a novel model system for proteolytically mediated cell migration. *Biophysical Journal*. **89** (2), 1374-1388 (2005).

27. Bruns, J., Egan, T., Mercier, P., Zustiak, S. P. Glioblastoma spheroid growth and chemotherapeutic responses in single and dual-stiffness hydrogels. *Acta Biomaterialia*. **163**, 400-414 (2023).

28. Kuwajima, T. et al. ClearT: a detergent-and solvent-free clearing method for neuronal and non-neuronal tissue. *Development*. **140** (6), 1364-1368 (2013).

29. Holt, S. E., Ward, E. S., Ober, R. J., Alge, D. L. Shooting for the moon: using tissue-mimetic hydrogels to gain new insight on cancer biology and screen therapeutics. *MRS Communications*. **7** (3), 427-441 (2017).

30. Jain, E., Scott, K. M., Zustiak, S. P., Sell, S. A. Fabrication of polyethylene glycol-based hydrogel microspheres through electrospraying. *Macromolecular Materials and Engineering*. **300** (8), 823-835 (2015).

31. Raghavan, S. et al. Comparative analysis of tumor spheroid generation techniques for differential *in vitro* drug toxicity. *Oncotarget*. **7** (13), 16948 (2016).

32. Lee, K. -H., Kim, T. -H. Recent advances in multicellular tumor spheroid generation for drug screening. *Biosensors*. **11** (11), 445 (2021).